# Water Heater Unit



Thermo Top E Additional Heater 00 0003 Thermo Top C Additional Heater 00 0002 Thermo Top P Additional Heater 00 0104

# **Installation Instructions**

# Peugeot 3008

Diesel

from Model Year 2009 Left-hand drive vehicle Manual transmission Automatic air-conditioning



### WARNING!

Hazard warning:

Incorrect installation or repair of Webasto heating systems may cause a fire or result in the emission of carbon monoxide, which can be fatal. Serious or fatal injuries can be caused as a result.



Specialist company training, technical documentation, specialized tools and equipment are required to install and repair Webasto heating and cooling systems.

Only genuine Webasto parts may be used. See also Webasto air and water heaters accessories catalogue.

NEVER attempt to install or repair Webasto heating or cooling systems if you have not successfully completed the company training and thereby acquired the required technical skills, or if you do not have access to the required technical documentation, tools and equipment needed to carry out correct installation and repairs.

ALWAYS follow all Webasto installation and repair instructions and observe all warnings.

Webasto does not accept any liability for defects and damage that are attributable to installation by untrained staff.

		Peugeot 3	800	
Table of Contents				
Validity Heater Unit/Installation Kit Foreword General Instructions Special Tools Explanatory Notes on Document Preliminary Work Heater unit installation location Preparing electrical system Electrical system Fan controller Remote option (Telestart)	2 3 3 3 4 5 5 6 7 8 10	Preparing installation location Installing heater unit Coolant circuit Fuel Combustion air Exhaust gas Final Work Coding BSI Central switching unit Operating Instructions for End Customer	11 12 13 17 20 21 23 23 24	

## Validity

Manufacturer	Model	Туре	EG-BE No./ABE
Peugeot	3008	OU	e2 * 2001 / 116 * 0377 *
<b>–</b> • •			
Engine type	Engine model	Output in kW	Displacement in cm <sup>3</sup>
RHE	Diesel	110	1997

Vehicle and engine types, equipment variants and national specifications not listed in these installation instructions have not been tested. However, installation according to these installation instructions may be possible.

The installation location of the digital timer should be confirmed with the end customer before installation.

### Heater Unit/Installation Kit

Quantity	Description	Order No.:
1	Retail accessories Thermo Top E / C / P	See price list
1	Installation kit for Peugeot 3008 2009 Diesel	1315209A
1	Heater control	See price list

#### Heater unit recommended for the respective vehicle class:

Vehicle	Heater Unit
Compact car	Thermo Top E
Mid-size car, station wagon	Thermo Top C
Full-size car, van, offroader	Thermo Top P

The selection of the heater unit is based on the passenger compartment size of the vehicle and the level of comfort required by the customer!

### Foreword

These installation instructions apply to Peugeot 3008 Diesel vehicles - for validity, see page 2 - from model year 2009 and later, assuming technical modifications to the vehicle do not affect installation, any liability claims excluded. Depending on the vehicle version and equipment, modifications may be necessary during installation with respect to these installation instructions.

However, the stipulations in the "installation instructions" and "operating and maintenance instructions" for the *Thermo Top C/P/E* must always be observed.

The corresponding rules of technology and any information from the vehicle manufacturer should be observed during the installation work.

### **General Instructions**

Installation should be carried out according to the general, standard rules of technology. Unless specified otherwise, fasten hoses, lines and wiring harnesses to original vehicle lines and wiring harnesses using cable ties.

Sharp edges must be provided with rub protection (cut-open fuel hose)!


Spray unfinished body areas, e.g. drilled holes, with anti-corrosion wax (Tectyl 100K, Order No. 111329).

### **Special Tools**

- Torque wrench for 2.0 10 Nm
- Hose clamping pliers
- Metric thread-setter kit

## **Explanatory Notes on Document**

To provide you with a quick overview of the individual working steps, you will find an identification mark on the outside top right corner of the page in question.



Specific risk of damage to components.

Specific risk of fire or explosion.

Reference to general installation instructions of Webasto components or to the manufacturer's vehicle-specific documents.

Reference to a special technical feature.

The arrow in the vehicle icon indicates the position on the vehicle and the viewing angle.


All dimensions are in mm! Tightening torque of hose clamps = 2.0 + 0.5 Nm! Tightening torque of Ejot screws, Ejot studs = 10 Nm!

### **Preliminary Work**

### WARNING!

- Disconnect the battery "earth" or "ground" connection.
- Depressurize the cooling system.
- Copy the factory number from the original type label to the duplicate type label.
- Remove years that do not apply from the duplicate label.
- Attach the duplicate label (type label) in the appropriate place.
- Open the fuel tank cap and vent the fuel tank.
- Close the tank cap again.
- Remove engine design cover
- Remove air filter box
- Remove charge-air tube with bracket (bolts will be reused)
- Completely remove the battery and the battery carrier.
- Remove front underride protection
- Remove the right rear underride protection.


Remove page 24 "Operating Instructions for End Customer" and add to vehicle operating instructions!



### Heater unit installation location

1 Heater unit

Installation location




Strip insulation from approx. 500 mm of wiring harness of digital timer 3. Detach 0.75<sup>2</sup> brown (br) wire 1 from wiring harness, crimp on microtimer and then re-insulate remaining wires!

Preparing wiring harness of digital timer

S.

6

5



2

4

1

3

2

2

3

wires 3.

to K3/87.


## **Electrical system**

### Positive and ground wire

- 1 Positive red (rt) wire on original vehicle positive support point
- 2 Brown (br) ground wire on original vehicle ground support point

### **Digital timer**

1 Digital timer




### Wiring harness pass through

Route wiring harnesses (digital timer, fan controller and green/white (gn/ws) wire in protective sleeving) on original vehicle wiring harness 1 to protective rubber plug 2 and route into passenger compartment.


### Fuse holder, K3 relay


- 1 Retaining plate for fuse holder
- 2 4 mm dia. hole, 5.5x13 self-tapping screw; plastic nut [2x each]
- 3 K3 relay
- 4 Fuse holder

[i]



- Press in locking lug 1 and fold down bar 3.
- 2 20-pin blue connector





connector off BSI and removing


Pulling


Connection on 20-pin blue (bl) connector **2** from BSI. Insert microtimer from brown (br) wire **1** in PIN 6. Complete BSI connector and mount.


Route wiring harness of digital timer upward to installation location of digital timer. Produce connections as shown in wiring diagram.

Connection of BSI

		13	
1 2	Remote option (Telestart)	i	
-4	Fasten receiver <b>2</b> with adhesive tape onto cross member <b>1</b> !	1	
		Installing receiver	
912			
12			
1	1 Antenna		
A State of the			
		Installing antenna	
13			
44	Temperature sensor for HTM100 only	i	
	1 Fasten temperature sensor with adhesive tape		
		Installing tempera- ture senso	)r
14			








Peugeot 3008	
Hose <b>A</b> = 180° (18x18) molded hose Discard section <b>X</b> <b>B</b> = 630 <b>C</b> = 130 <b>D</b> = 500	Cutting coolant hoses to length
Push braided protection hoses onto hose <b>B</b> and <b>D</b> and cut to length. Cut heat shrink plastic tubing to length and shrink to size.	
<b>1</b> 50 mm long heat shrink plastic tubing [4x]	Preparing coolant hoses
Remove original vehicle hose on engine out- let/heat exchanger inlet <b>1</b> .	Cutting point
Remove braided protection hose in area of cutting point <b>2</b> . Remount hose section of heat exchanger inlet <b>1</b> and hose section engine outlet <b>3</b> !	Separating

1315210A\_EN





Peugeot 3008	
Push black (sw) rubber isolator <b>1</b> onto hose <b>B</b> and align on charge-air tube.	Connect- ing heater unit inlet
Route hose <b>B</b> through 48 mm dia. rubber- coated p-clamp <b>1</b> .	Routing in engine compart- ment
<ul><li>Push black (sw) rubber isolator 2 onto hose B.</li><li>1 Engine-outlet hose section</li></ul>	Connect- ing engine outlet
<ul> <li>Mount black (sw) rubber isolator 2 to original vehicle bracket 4. Ensure sufficient distance to adjacent components; correct if necessary.</li> <li>1 Cable tie [2x]</li> <li>2 Insert spacer bracket</li> </ul>	Connect- ing engine outlet

1315210A\_EN

### Fuel

### **CAUTION!**

Open the vehicle's fuel tank cap, ventilate the tank and then re-close the tank lock.


Catch any fuel running off with an appropriate container.

Install fuel line and metering-pump wiring harness so that they are protected against stone impact. Unless specified otherwise, always fasten using cable ties. Mount the fuel line and wiring harness with rub protection on sharp edges.

### WARNING!

The fuel line and wiring harness are routed to the metering pump in as shown in the wiring harness routing diagram.

35




Route fuel line **1** in 2,100 mm corrugated tube to firewall.


**2** Hose section, 10 mm dia. clamp [2x]







Connection on heater unit







1315210A\_EN



2

- 1 Wiring harness of metering pump, connector mounted
- 2 Fuel line from heater unit, hose section, 10 mm dia. clamp [2x]

Connecting to metering pump

[i]

Cut off fuel supply line **3** at Position **2**.


40

41

- **1** Hose section, 10 mm dia. clamp [2x]
- **2** 8x5x8 fuel standpipe, 10 mm dia. clamp [2x]



Removing fuel



Push fabric protective hose **2** onto fuel line of T-piece **3**. Check the position of the components; adjust if necessary. Check that they have free clearance.

1 180° molded hose, 10 mm dia. clamp [2x]

Connecting to metering pump


Ĭ i ]

ſ

3

6

Cutting combustion air pipe to length



44

i

Installing combustion air pipe

Installing muffler

	Peugeot 3008	
a b b	<ul> <li>Exhaust gas</li> <li>1 Exhaust pipe a = 290</li> <li>2 Exhaust end section b = 250</li> </ul>	Preparing exhaust pipe
	When drilling, watch components located be- hind! 1 7 mm dia. hole	Drilling hole in cross member
	<ol> <li>Muffler</li> <li>M6x50 bolt, spring lockwasher, 30 mm shim, flanged nut</li> </ol>	Installing muffler
	<ol> <li>Hose clamp [2x]</li> <li>Exhaust pipe</li> </ol>	Installing exhaust pipe


) (

1 Exhaust end section

2 Angle bracket

1

3 M6x20 bolt, p-clamp, flanged nut



1315210A\_EN

1

*i* ]

## **Final Work**


### WARNING!

Mount removed parts in reverse order. Check all hoses, clamps and all electrical connections for firm seating. Secure all loose cables using cable ties. Only use manufacturer-approved coolant. Spray heater unit components with anti-corrosion wax (Tectyl 100K, Order No. 111329).

- Connect the battery.
- Fill and bleed the coolant circuit according to the vehicle manufacturer's specifications.
- Set the digital timer.
- Check the proper operation of the additional heater, see the operating instructions/installation instructions.
- Attach the "Switch off additional heater before refueling" sticker near the filler neck

## **Coding BSI Central switching unit**

The BSI central switching unit has to be configured as follows:





Webasto AG Postfach 80 D-82131 Stockdorf / Germany National Hotline: 01805 93 22 78 (14 Cent aus dem deutschen Festnetz) Hotfax: 0395 5592 353 Hotmail: hotline@webasto.de http://www.webasto.de

Printed in Germany

## **Operating Instructions for End Customer**

Please remove page and add to the vehicle operating instructions.

### Note:

We recommend matching the heating time to the driving time.

Heating time = driving time

## Example:

For a driving time of approx. 20 min. (in one direction), we recommend not exceeding a switch-on time of 20 min.

On vehicles with anti-theft alarm, the passenger compartment monitoring system must be deactivated. For information on deactivation, please see the vehicle owner's manual.

No further settings on the vehicle are required!

i